


Mandril Manual HSS - Série 670

Categorias

• HSS



| Ref. | Descrição | D1 | L1 | L2 |
|-----------------|-------------------------------|-----|----|----|
| 290100006700100 | Mandril Manual HSS - 1 X 16 | 1 | 34 | 16 |
| 290100006700110 | Mandril Manual HSS - 1,1 X 16 | 1,1 | 34 | 16 |
| 290100006700120 | Mandril Manual HSS - 1,2 X 16 | 1,2 | 34 | 16 |
| 290100006700130 | Mandril Manual HSS - 1,3 X 16 | 1,3 | 34 | 16 |
| 290100006700140 | Mandril Manual HSS - 1,4 X 20 | 1,4 | 41 | 20 |
| 290100006700150 | Mandril Manual HSS - 1,5 X 20 | 1,5 | 41 | 20 |
| 290100006700160 | Mandril Manual HSS - 1,6 X 21 | 1,6 | 44 | 21 |
| 290100006700170 | Mandril Manual HSS - 1,7 X 21 | 1,7 | 44 | 21 |
| 290100006700180 | Mandril Manual HSS - 1,8 X 23 | 1,8 | 47 | 23 |
| 290100006700190 | Mandril Manual HSS - 1,9 X 23 | 1,9 | 47 | 23 |
| 290100006700200 | Mandril Manual HSS - 2 X 25 | 2 | 50 | 25 |
| 290100006700210 | Mandril Manual HSS - 2,1 X 26 | 2,1 | 52 | 26 |
| 290100006700220 | Mandril Manual HSS - 2,2 X 26 | 2,2 | 52 | 26 |
| 290100006700230 | Mandril Manual HSS - 2,3 X 26 | 2,3 | 52 | 26 |
| 290100006700240 | Mandril Manual HSS - 2,4 X 29 | 2,4 | 58 | 29 |
| 290100006700250 | Mandril Manual HSS - 2,5 X 29 | 2,5 | 58 | 29 |
| 290100006700260 | Mandril Manual HSS - 2,6 X 29 | 2,6 | 58 | 29 |
| 290100006700270 | Mandril Manual HSS - 2,7 X 29 | 2,7 | 58 | 29 |
| 290100006700280 | Mandril Manual HSS - 2,8 X 29 | 2,8 | 58 | 29 |
| 290100006700290 | Mandril Manual HSS - 2,9 X 29 | 2,9 | 58 | 29 |
| 290100006700300 | Mandril Manual HSS - 3 X 31 | 3 | 58 | 31 |
| 290100006700310 | Mandril Manual HSS - 3,1 X 33 | 3,1 | 66 | 33 |
| 290100006700320 | Mandril Manual HSS - 3,2 X 33 | 3,2 | 66 | 33 |
| 290100006700330 | Mandril Manual HSS - 3,3 X 33 | 3,3 | 66 | 33 |
| 290100006700340 | Mandril Manual HSS - 3,4 X 35 | 3,4 | 71 | 35 |
| 290100006700350 | Mandril Manual HSS - 3,5 X 35 | 3,5 | 71 | 35 |

| Ref. | Descrição | D1 | L1 | L2 |
|-----------------|-------------------------------|-----|-----|----|
| 290100006700360 | Mandril Manual HSS - 3,6 X 35 | 3,6 | 71 | 35 |
| 290100006700370 | Mandril Manual HSS - 3,7 X 35 | 3,7 | 71 | 35 |
| 290100006700380 | Mandril Manual HSS - 3,8 X 38 | 3,8 | 76 | 38 |
| 290100006700390 | Mandril Manual HSS - 3,9 X 38 | 3,9 | 76 | 38 |
| 290100006700400 | Mandril Manual HSS - 4 X 38 | 4 | 76 | 38 |
| 290100006700410 | Mandril Manual HSS - 4,1 X 38 | 4,1 | 76 | 38 |
| 290100006700420 | Mandril Manual HSS - 4,2 X 38 | 4,2 | 76 | 38 |
| 290100006700430 | Mandril Manual HSS - 4,3 X 41 | 4,3 | 81 | 41 |
| 290100006700440 | Mandril Manual HSS - 4,4 X 41 | 4,4 | 81 | 41 |
| 290100006700450 | Mandril Manual HSS - 4,5 X 41 | 4,5 | 81 | 41 |
| 290100006700460 | Mandril Manual HSS - 4,6 X 41 | 4,6 | 81 | 41 |
| 290100006700470 | Mandril Manual HSS - 4,7 X 41 | 4,7 | 81 | 41 |
| 290100006700480 | Mandril Manual HSS - 4,8 X 44 | 4,8 | 87 | 44 |
| 290100006700490 | Mandril Manual HSS - 4,9 X 44 | 4,9 | 87 | 44 |
| 290100006700500 | Mandril Manual HSS - 5 X 44 | 5 | 87 | 44 |
| 290100006700510 | Mandril Manual HSS - 5,1 X 44 | 5,1 | 87 | 44 |
| 290100006700520 | Mandril Manual HSS - 5,2 X 44 | 5,2 | 87 | 44 |
| 290100006700530 | Mandril Manual HSS - 5,3 X 44 | 5,3 | 87 | 44 |
| 290100006700540 | Mandril Manual HSS - 5,4 X 47 | 5,4 | 93 | 47 |
| 290100006700550 | Mandril Manual HSS - 5,5 X 47 | 5,5 | 93 | 47 |
| 290100006700560 | Mandril Manual HSS - 5,6 X 47 | 5,6 | 93 | 47 |
| 290100006700570 | Mandril Manual HSS - 5,7 X 47 | 5,7 | 93 | 47 |
| 290100006700580 | Mandril Manual HSS - 5,8 X 47 | 5,8 | 93 | 47 |
| 290100006700590 | Mandril Manual HSS - 5,9 X 47 | 5,9 | 93 | 47 |
| 290100006700600 | Mandril Manual HSS - 6 X 47 | 6 | 93 | 47 |
| 290100006700610 | Mandril Manual HSS - 6,1 X 50 | 6,1 | 100 | 50 |
| 290100006700620 | Mandril Manual HSS - 6,2 X 50 | 6,2 | 100 | 50 |
| 290100006700630 | Mandril Manual HSS - 6,3 X 50 | 6,3 | 100 | 50 |
| 290100006700640 | Mandril Manual HSS - 6,4 X 50 | 6,4 | 100 | 50 |
| 290100006700650 | Mandril Manual HSS - 6,5 X 50 | 6,5 | 100 | 50 |
| 290100006700660 | Mandril Manual HSS - 6,6 X 50 | 6,6 | 100 | 50 |
| 290100006700670 | Mandril Manual HSS - 6,7 X 50 | 6,7 | 100 | 50 |
| 290100006700680 | Mandril Manual HSS - 6,8 X 54 | 6,8 | 107 | 54 |
| 290100006700690 | Mandril Manual HSS - 6,9 X 54 | 6,9 | 107 | 54 |
| 290100006700700 | Mandril Manual HSS - 7 X 54 | 7 | 107 | 54 |
| 290100006700710 | Mandril Manual HSS - 7,1 X 54 | 7,1 | 107 | 54 |
| 290100006700720 | Mandril Manual HSS - 7,2 X 54 | 7,2 | 107 | 54 |
| 290100006700730 | Mandril Manual HSS - 7,3 X 54 | 7,3 | 107 | 54 |
| 290100006700740 | Mandril Manual HSS - 7,4 X 54 | 7,4 | 107 | 54 |
| 290100006700750 | Mandril Manual HSS - 7,5 X 54 | 7,5 | 107 | 54 |
| 290100006700760 | Mandril Manual HSS - 7,6 X 58 | 7,6 | 115 | 58 |
| 290100006700770 | Mandril Manual HSS - 7,7 X 58 | 7,7 | 115 | 58 |
| 290100006700780 | Mandril Manual HSS - 7,8 X 58 | 7,8 | 115 | 58 |

| Ref. | Descrição | D1 | L1 | L2 |
|-----------------|--------------------------------|------|-----|----|
| 290100006700790 | Mandril Manual HSS - 7,9 X 58 | 7,9 | 115 | 58 |
| 290100006700800 | Mandril Manual HSS - 8 X 58 | 8 | 115 | 58 |
| 290100006700810 | Mandril Manual HSS - 8,1 X 58 | 8,1 | 115 | 58 |
| 290100006700820 | Mandril Manual HSS - 8,2 X 58 | 8,2 | 115 | 58 |
| 290100006700830 | Mandril Manual HSS - 8,3 X 58 | 8,3 | 115 | 58 |
| 290100006700840 | Mandril Manual HSS - 8,4 X 58 | 8,4 | 115 | 58 |
| 290100006700850 | Mandril Manual HSS - 8,5 X 58 | 8,5 | 115 | 58 |
| 290100006700860 | Mandril Manual HSS - 8,6 X 62 | 8,6 | 124 | 62 |
| 290100006700870 | Mandril Manual HSS - 8,7 X 62 | 8,7 | 124 | 62 |
| 290100006700880 | Mandril Manual HSS - 8,8 X 62 | 8,8 | 124 | 62 |
| 290100006700890 | Mandril Manual HSS - 8,9 X 62 | 8,9 | 124 | 62 |
| 290100006700900 | Mandril Manual HSS - 9 X 62 | 9 | 124 | 62 |
| 290100006700910 | Mandril Manual HSS - 9,1 X 62 | 9,1 | 124 | 62 |
| 290100006700920 | Mandril Manual HSS - 9,2 X 62 | 9,2 | 124 | 62 |
| 290100006700930 | Mandril Manual HSS - 9,3 X 62 | 9,3 | 124 | 62 |
| 290100006700940 | Mandril Manual HSS - 9,4 X 62 | 9,4 | 124 | 62 |
| 290100006700950 | Mandril Manual HSS - 9,5 X 62 | 9,5 | 124 | 62 |
| 290100006700960 | Mandril Manual HSS - 9,6 X 66 | 9,6 | 133 | 66 |
| 290100006700970 | Mandril Manual HSS - 9,7 X 66 | 9,7 | 133 | 66 |
| 290100006700980 | Mandril Manual HSS - 9,8 X 66 | 9,8 | 133 | 66 |
| 290100006700990 | Mandril Manual HSS - 9,9 X 66 | 9,9 | 133 | 66 |
| 290100006701000 | Mandril Manual HSS - 10 X 66 | 10 | 133 | 66 |
| 290100006701010 | Mandril Manual HSS - 10,1 X 66 | 10,1 | 133 | 66 |
| 290100006701020 | Mandril Manual HSS - 10,2 X 66 | 10,2 | 133 | 66 |
| 290100006701030 | Mandril Manual HSS - 10,3 X 66 | 10,3 | 133 | 66 |
| 290100006701040 | Mandril Manual HSS - 10,4 X 66 | 10,4 | 133 | 66 |
| 290100006701050 | Mandril Manual HSS - 10,5 X 66 | 10,5 | 133 | 66 |
| 290100006701060 | Mandril Manual HSS - 10,6 X 71 | 10,6 | 142 | 71 |
| 290100006701070 | Mandril Manual HSS - 10,7 X 71 | 10,7 | 142 | 71 |
| 290100006701080 | Mandril Manual HSS - 10,8 X 71 | 10,8 | 142 | 71 |
| 290100006701090 | Mandril Manual HSS - 10,9 X 71 | 10,9 | 142 | 71 |
| 290100006701100 | Mandril Manual HSS - 11 X 71 | 11 | 142 | 71 |
| 290100006701110 | Mandril Manual HSS - 11,1 X 71 | 11,1 | 142 | 71 |
| 290100006701120 | Mandril Manual HSS - 11,2 X 71 | 11,2 | 142 | 71 |
| 290100006701130 | Mandril Manual HSS - 11,3 X 71 | 11,3 | 142 | 71 |
| 290100006701140 | Mandril Manual HSS - 11,4 X 71 | 11,4 | 142 | 71 |
| 290100006701150 | Mandril Manual HSS - 11,5 X 71 | 11,5 | 142 | 71 |
| 290100006701160 | Mandril Manual HSS - 11,6 X 71 | 11,6 | 142 | 71 |
| 290100006701170 | Mandril Manual HSS - 11,7 X 71 | 11,7 | 142 | 71 |
| 290100006701180 | Mandril Manual HSS - 11,8 X 76 | 11,8 | 152 | 76 |
| 290100006701190 | Mandril Manual HSS - 11,9 X 76 | 11,9 | 152 | 76 |
| 290100006701200 | Mandril Manual HSS - 12 X 76 | 12 | 152 | 76 |
| 290100006701250 | Mandril Manual HSS - 12,5 X 76 | 12,5 | 152 | 76 |

| Ref. | Descrição | D1 | L1 | L2 |
|-----------------|---------------------------------|------|-----|-----|
| 290100006701300 | Mandril Manual HSS - 13 X 76 | 13 | 152 | 76 |
| 290100006701350 | Mandril Manual HSS - 13,5 X 81 | 13,5 | 163 | 81 |
| 290100006701400 | Mandril Manual HSS - 14 X 81 | 14 | 163 | 81 |
| 290100006701450 | Mandril Manual HSS - 14,5 X 81 | 14,5 | 163 | 81 |
| 290100006701500 | Mandril Manual HSS - 15 X 81 | 15 | 163 | 81 |
| 290100006701550 | Mandril Manual HSS - 15,5 X 87 | 15,5 | 175 | 87 |
| 290100006701600 | Mandril Manual HSS - 16 X 87 | 16 | 175 | 87 |
| 290100006701650 | Mandril Manual HSS - 16,5 X 87 | 16,5 | 175 | 87 |
| 290100006701700 | Mandril Manual HSS - 17 X 87 | 17 | 175 | 87 |
| 290100006701750 | Mandril Manual HSS - 17,5 X 93 | 17,5 | 188 | 93 |
| 290100006701800 | Mandril Manual HSS - 18 X 93 | 18 | 188 | 93 |
| 290100006701850 | Mandril Manual HSS - 18,5 X 93 | 18,5 | 188 | 93 |
| 290100006701900 | Mandril Manual HSS - 19 X 93 | 19 | 188 | 93 |
| 290100006701950 | Mandril Manual HSS - 19,5 X 100 | 19,5 | 201 | 100 |
| 290100006702000 | Mandril Manual HSS - 20 X 100 | 20 | 201 | 100 |
| 290100006702100 | Mandril Manual HSS - 21 X 107 | 21 | 215 | 107 |
| 290100006702200 | Mandril Manual HSS - 22 X 107 | 22 | 215 | 107 |
| 290100006702300 | Mandril Manual HSS - 23 X 107 | 23 | 215 | 107 |
| 290100006702400 | Mandril Manual HSS - 24 X 115 | 24 | 231 | 115 |
| 290100006702500 | Mandril Manual HSS - 25 X 115 | 25 | 231 | 115 |
| 290100006702600 | Mandril Manual HSS - 26 X 115 | 26 | 231 | 115 |
| 290100006702700 | Mandril Manual HSS - 27 X 124 | 27 | 247 | 124 |
| 290100006702800 | Mandril Manual HSS - 28 X 124 | 28 | 247 | 124 |
| 290100006702900 | Mandril Manual HSS - 29 X 124 | 29 | 247 | 124 |
| 290100006703000 | Mandril Manual HSS - 30 X 124 | 30 | 247 | 124 |
| 290100006703100 | Mandril Manual HSS - 31 X 133 | 31 | 265 | 133 |
| 290100006703200 | Mandril Manual HSS - 32 X 133 | 32 | 265 | 133 |