


## Cabeça Roscada - APKT

Categorias

• Z



Ref.	Descrição	ØD	ØD1	L	ap	MD	Z
5821016APKT11M8	Cabeça Roscada 16-APKT11-M8-02	16	12.5	25	10.5	8	2
582120APKT11M10	Cabeça Roscada 20-APKT11-M10-03	20	18	30	10.5	10	3
582125APKT11M12	Cabeça Roscada 25-APKT11-M12-04	25	21	35	10.5	12	4
582132APKT11M16	Cabeça Roscada 32-APKT11-M16-05	32	29	43	10.5	16	5
582140APKT11M16	Cabeça Roscada 40-APKT11-M16-06	40	29	43	10.5	16	6
582125APKT16M12	Cabeça Roscada 25-APKT16-M12-02	25	21	38	10.5	12	2
582132APKT16M16	Cabeça Roscada 32-APKT16-M16-03	32	29	46	10.5	16	3
582140APKT16M16	Cabeça Roscada 40-APKT16-M16-04	40	29	46	10.5	16	4